

SONY®

# TRINITRON® COLOR TV


(CABLE COMPATIBLE TV)

## OPERATING INSTRUCTIONS

Before operating the unit, please read this manual thoroughly and retain it for future reference.

### WARNING

To prevent fire or shock hazard, do not expose the set to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**CAUTION.**  
TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

## OWNER'S RECORD

The model and serial numbers are located on the right side. Record these numbers in the spaces provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. KV19D8R Serial No. \_\_\_\_\_

### PRECAUTIONS

#### Safety

- Operate the unit only on 120 V AC.
- One blade of the plug is wider than the other for the purpose of safety and will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- Should any liquid or solid object fall into the cabinet, unplug the unit and have it checked by qualified personnel before operating it any further.
- Unplug the unit from the wall outlet if it is not going to be used for several days or more. To disconnect the cord, pull it out by the plug. Never pull the cord itself.

#### Installation

- To prevent internal heat build-up, do not block the ventilation openings.
- Do not install the unit in a hot or humid place or in a place subject to excessive dust or mechanical vibration.

#### Cleaning

Clean the unit with a slightly damp soft cloth. Use a mild household detergent. Never use strong solvents such as thinner or benzene as they might damage the finish of the cabinet.

#### Repacking


Retain the original carton and packing materials for safe transport of this unit in the future.

Use of this television receiver for other than private viewing of programs broadcast on UHF or VHF or transmitted by cable companies for the use of the general public may require authorization from the broadcaster/cable company and/or program owner.



## PRESETTING CHANNELS

Use the supplied Sony RM-717 Remote Commander.



VHF: 2-13

UHF: 14-69

CATV: 1-125

By adding and erasing channels, you can preset your TV so that only the desired channels appear in sequence when CHANNEL +/- is pressed.

### PREPARATION

- 1 Turn on TV.
- 2 Set the NORMAL/CATV selector to the proper mode.  
For VHF and UHF channels: NORMAL  
For cable TV channels: CATV

### ADDING CHANNELS

- 1 Select the channel to be added by pressing the channel number buttons and then ENTER.
  - 2 Press ADD.  
A "+" indication will appear on the left of the channel display on the screen, indicating that the channel has been included in the proper numerical sequence when you press CHANNEL +/-.
- Repeat steps 1 and 2 for other channels to be added.

### ERASING CHANNELS

- 1 Select the channel to be erased.
- 2 Press ERASE.  
A "-" indication will appear on the left of the channel display on the screen, indicating that the channel has been erased. When CHANNEL +/- is pressed, you will see that the channel is skipped over in the numerical sequence.

Repeat steps 1 and 2 for other channels to be erased. To add erased channels again, follow the steps in "ADDING CHANNELS".

#### Note

You cannot erase a VHF or UHF channel from the memory and retain the cable TV channel which has the same number, or vice versa. If either a VHF/UHF channel or a cable TV channel with the same number is to be kept in the memory, do not erase the number.

### CABLE TV CHANNEL CHART\*\*

Cable TV systems use letters or numbers to designate channels. To tune in a channel, refer to this chart.

Check with your local cable TV company for more complete information on the available channels.


Number on this TV	1	5	6	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
Corresponding CATV channel	A-8	A-7	A-6	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
31 32 33 34 35 36	37	38	39	.....	93	94	95	96	97	98	99	100	101	102	.....	123	124	125		
R S T U V W	W+1	W+2	W+3	.....	W+57	W+58	A-5	A-4	A-3	A-2	A-1	W+59	W+60	W+61	.....	W+82	W+83	W+84		

#### Note

Pay cable TV systems use scrambled or encoded signals and require special converters (decoders) in addition to the normal cable connection.

\*\*The designation of the cable TV channels conforms to the EIA/NCTA recommendation.

# FUNCTION OF CONTROLS




## ON THE SET

- 1 Bar display**  
Indicates level of volume and picture contrast.
- 2 On-screen display**  
Shows channel numbers, "MUTING", and "SLEEP" indicators.
- 3 Remote control detector**  
Point the Remote Commander towards this detector.
- 4 SLEEP lamp**  
Lights up when the SLEEP button on the Remote Commander is pressed.
- 5 POWER switch**  
Depress the POWER switch to turn on the TV. To turn off the unit, press POWER again.
- 6 CHANNEL scan buttons**  
Press CH "+" for higher-numbered channels and "-" for lower-numbered channels.
- 7 VOLUME buttons**  
Press VOL "+" to increase volume, or "-" to decrease it.
- 8 PICTURE buttons**  
Press PICTURE "+" to increase picture contrast, or "-" to decrease it.

## INSIDE THE PANEL

- 9 ADD button**
- 10 ERASE button**
- 11 NORMAL/CATV selector**
- 12 HUE control**  
Turn clockwise to make the tones greenish or counterclockwise to make them purplish.
- 13 COLOR control**  
Turn clockwise for more color intensity or counterclockwise for less color intensity.
- 14 BRIGHT (brightness) control**  
Turn clockwise for more brightness or counterclockwise for less brightness.
- 15 SHARPNESS control**  
Turn clockwise for more sharpness or counterclockwise for less sharpness.



## REMOTE COMMANDER

### 16 MUTING button

To mute the sound immediately, press MUTING. Press it again to restore the sound.

### 17 Channel number buttons \*

### 18 DISPLAY button

Press DISPLAY to keep the display on the screen.

### 19 SLEEP button

Press to activate sleep timer.


Usually the Remote Commander is all that is needed to operate the TV in everyday use.

- 1 Turn the Remote Commander face down, press the tab and lift the cover.
- 2 Place batteries in the Commander with correct polarities, as illustrated inside the case.
- 3 Replace the cover.

## Notes

- Use 2 size AA batteries (IEC designation R6).
- In normal operation, batteries will last up to half a year. If the unit does not operate properly, the batteries might be exhausted. Replace all with new ones.
- To avoid damage from possible battery leakage, remove the batteries for extended unused periods.
- Be sure that there are no obstructions between the Commander and the TV.
- Operable range is limited.

Remote Commander RM-717



\*The functions of these buttons are not available on the TV.

## OPERATION

### Preparation

Set NORMAL/CATV selector to:  
NORMAL for normal VHF and UHF programs.  
CATV for cable TV programs.

### 1 Press POWER to turn on the TV.

The channel number will be displayed on the screen and the SLEEP lamp will light up for several seconds.

### 2 Select channels in one of the following two ways.

- Press the numeral(s) of the channel and then press ENTER.

Ex. To select channel 6, press 6 and then ENTER.

To select channel 125, press 1, 2, 5 and then ENTER.

If you pressed a wrong numeral, wait for a few seconds and it will disappear. Then try again.

- Press CH "+" for higher-numbered channels and "-" for lower-numbered channels. Preset channels will appear in sequence. (For presetting desired channels, see "PRESETTING CHANNELS".)

The channel display will remain on the screen for a few seconds. To keep the display on the screen, press DISPLAY.

### 3 Adjust volume and picture to your preference, if necessary.

Press VOL "+" to increase volume, or "-" to decrease it. Press PICTURE "+" to increase picture contrast, or "-" to decrease it.

## FEATURES

- **New Black-tinted Trinitron** picture tube absorbs most ambient light and remarkably improves picture contrast.
- **New Sharp Focus Electron Gun** delivers clear and crisp images with remarkably improved sharpness all the way to the screen's edges and corners.
- **Remote control Trinitron color television**
- **Multi-band VHF/UHF/CATV tuning**
- **Sleep timer**, which automatically turns the unit off after one hour
- **MPX (multiplex) OUT jack**, which allows a special adaptor (optional) to be connected for any future multichannel TV sound (MTS) stereo or bilingual broadcasts
- **On-screen display**
- **DYNAMIC COLOR™ system** for superior color reproduction with natural facial color tones and dazzling whites
- **DYNAMIC PICTURE™ system**, which adjusts picture contrast automatically to produce more detail in both bright and dark areas of every scene
- **ECONOQUICK™**, energy-saving, quick-start picture system



## SPECIFICATIONS

Television system	American TV standards
Channel coverage	VHF: 2-13 UHF: 14-69 Cable TV: 1-125
Picture tube	Trinitron tube <b>19-inch picture measured diagonally</b> 20-inch picture tube measured diagonally
Output	MPX output (phono jack) 77.5 mVrms Load impedance 10 kilohms (main channel, 1 kHz, 100% modulation)
Power requirements	120 V AC, 60 Hz
Power consumption	120 W (max.), 78 W (average) 6 W (in standby condition)
Accessories supplied	Remote Commander RM-717 with 2 size AA batteries

Design and specifications subject to change without notice.

## TROUBLESHOOTING

Disturbances in picture and sound can often be eliminated by checking the symptoms and following the suggestions listed below.

SYMPTOM	CHECK AND ADJUST
Poor or no picture (screen not lit), good sound	<ul style="list-style-type: none"> <li>• Adjust PICTURE.</li> <li>• Adjust BRIGHT.</li> <li>• Re-orient antenna. Check antenna/cable connections.</li> </ul>
Good picture, no sound	<ul style="list-style-type: none"> <li>• Press VOLUME +.</li> <li>• Release MUTING on the Remote Commander.</li> </ul>
No picture (screen not lit), no sound	Is POWER switched on? Power in outlet?
No color	Is it a color program?
Snow and noise only	<ul style="list-style-type: none"> <li>• Is it an active or the correct channel?</li> <li>• Check the NORMAL/CATV selector setting.</li> <li>• Check antenna connections.</li> </ul>
 Dotted lines or stripes	This is often caused by local interference (e.g. cars, neon signs, hair-dryers etc.). Adjust antenna for minimum interference.
 Double images or ghosts	Reflections from nearby mountains or buildings often cause this problem. A highly directional outdoor antenna or a CATV cable may improve the picture.
Try another channel. It could be station trouble.	

If the problem still cannot be solved, contact your nearest service facility.


## ANTENNA/CABLE CONNECTION

### INDOOR ANTENNA ADJUSTMENT

For VHF/UHF reception, use the attached telescopic dipole antenna. It will provide good reception in most areas.

Adjust the length, direction and angle of both elements symmetrically until the picture is clearest.

Rear of TV




### OUTDOOR ANTENNA CONNECTION

If you cannot obtain satisfactory reception with the dipole antenna, using an outdoor antenna may be necessary. Cable TV reception is only possible by connecting a cable supplied by your local cable operator.

#### A Combination VHF/UHF antenna,\* VHF antenna, UHF antenna or CATV cable


Select the proper connector according to the cable type.

When the cable is a 75-ohm coaxial type (round)




Use an optional F-type connector.

When the cable is a 300-ohm ribbon type lead-in (flat)



Attach the antenna connector which was fixed to the indoor antenna.




\*Most combination antennas are equipped with a signal splitter. Take off the splitter and attach the proper connector.

- 1 Remove the indoor antenna from the antenna terminal of the TV.
- 2 Prepare the antenna or cable end using the appropriate connector, and connect the antenna or cable to the antenna terminal of the TV. (See A or B below.)

#### B When both VHF and UHF antennas are connected

Prepare the VHF antenna end using the appropriate connector as illustrated in A.

Attach an optional EAC-66 U/V mixer to the TV antenna terminal, and connect the cables to the U/V mixer.



#### Note

When the cable is connected to the TV with the U/V mixer, snow and noise may appear in the pictures of the cable TV channels over 37 (W + 1).

#### Note to CATV system installer in the U.S.A.

This reminder is provided to call the CATV system installer's attention to Article 820-22 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

## MPX OUT JACK USAGE

#### Caution

Before connecting, make sure that the power to each piece of equipment is turned off.

Connect to the MPX OUT jack on the rear of the unit an optional special adaptor for any multichannel TV sound (stereo or bilingual) broadcasts.